

SURFACE / READY TO USE DISINFECTANTS

DESCOCEPT PUR INDUSTRIAL WIPES



PRESERVE

ALCOHOL-IMPREGNATED WIPES FOR FAST DISINFECTION

1 / 3

Universal, comfortable and quick application

Comprehensive, fast effectiveness

**Particularly suitable for disinfection
of large areas in the food industry**

Residue-free rapid disinfection



DESOTEX®
Wipes
System

SURFACE / READY TO USE DISINFECTANTS

DESCOCEPT PUR INDUSTRIAL WIPES



PRESERVE

PRODUCT DESCRIPTION

2 / 3

DESCOCEPT PUR INDUSTRIAL WIPES are alcoholic, ready-to-use wipes for the disinfection and cleaning of surfaces of all kinds in the food producing and processing industry. **DESCOCEPT PUR INDUSTRIAL WIPES** offer a universal and time-saving application for the disinfection and cleaning of large surfaces and are therefore ideally suited for conveyor belts, packaging lines, plastic crates, scales, handles, work surfaces and machine and plant surfaces as well as knife

instruments and control panels. The impregnating solution is free of perfume and colorants and dries without leaving any residues. It is not necessary to wipe the surface again.

The wipes can be extracted individually from the practical wipes dispenser system with re-sealable lid.

APPLICATIONS AND NOTES

According to Biocidal Products Regulation (BPR)

Disinfection and cleaning of alcoholresistant areas and materials. Due to the perfume-free and residue-free formulation, particularly suitable for the food industry and kitchens.

Application

Wipe surfaces with DESCOCEPT PUR INDUSTRIAL WIPES until the surfaces are completely wetted and allow to dry for the entire contact time.

Application notes

Shelf life after opening the packaging: 28 days.

Composition

100 g solution includes: 45 g ethanol.

Precautionary and hazard statements

Flammable liquid and vapour. Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. Keep container tightly closed. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Dispose of contents/container to approved disposal company or local collection.

For professional use only.

Use disinfectants safely.

Always read the label and product information before use.

SURFACE / READY TO USE DISINFECTANTS

DESCOCEPT PUR INDUSTRIAL WIPES



PRESERVE

SPECTRUM OF EFFICACY AND CONTACT TIMES

3 / 3

SPECTRUM OF EFFICACY AND CONTACT TIMES			30 s	1 min	3 min
application recommendation for surface disinfection					
bactericidal, yeasticidal	EN 1276, EN 1650	clean and dirty conditions		•	
tuberculocidal (M. terrae)	EN 14348	clean conditions	•		
mycobactericidal (M. avium und M. terrae)	EN 14348	clean conditions		•	
active against enveloped viruses	EN 14476	clean and dirty conditions		•	
limited spectrum virucidal	EN 14476	clean conditions			•
additional test results					
active against adeno viruses	EN 14476	clean conditions			•
active against nor viruses (MNV)	EN 14476	clean conditions		•	

PURCHASING INFORMATION

Product	Single unit	Delivery unit	Content	Wipe size	REF
DESCOCEPT PUR INDUSTRIAL WIPES	dispenser	1	400 wipes	20 x 30 cm	00-323-ERS400-01
	refill	2	400 wipes	20 x 30 cm	00-323-RS400



CERTIFICATIONS



For an overview of our current certifications, scan the QR code to visit:

<https://www.schumacher-online.com/en/cert>

Dr. Schumacher is certified according to DIN EN 13485, DIN EN ISO 9001, DIN EN ISO 14001, BS OHSAS 18001, has a validated environment management system according to EMAS and is a member of IHO, VCI, BAH, DGSV and of the DGKH.